

DAIICHISEIKO

Wearable Fishing Trash Case

JUNK POCKET



Portable junk/trash can with belt and carabiner attached. A small pocket for junk and trash such as damaged worms, jig heads, and pieces of line that occur during light games!



DAIICHISEIKO JUNK POCKET

[CLICK HERE](#)

Line up



- Size: 75x70x25mm
- Weight: 21g
- Material: PP (polypropylene)

FEATURES

Exterior




Junk/garbage collection method



- 1 Open the rotating shutter with one hand, so you can quickly collect junk and garbage.
- 2 Hold the lid when disposing of junk/garbage.
- 3 Gently pull the main body in the direction of the arrow to open it!

Example of use / Installation example



Easy to attach vertically or horizontally to match the belt of your life jacket or bag, or attach it with a carabiner.



DAIICHISEIKO JUNK POCKET

[CLICK HERE](#)